



Instructions

Brake Caliper Medallion

NOTE

BQUAZY Sportster recommends installation be done by qualified individuals.

Our Medallions use 3M VHB 4905 which is a permanent vehicle adhesive and can not easily be removed.

Models

This Kit is designed to fit 2004 to 2013 XL Sportster model motorcycles, front or rear brake calipers.

Kit Contents

- 1 - Brake Caliper Medallion
- 1 - Alcohol wipe

1. The stock medallion is very thin and adhered with a thin adhesive. It can be removed by using a small hook or screw driver. **(Figure 1.)** It will bend and may not be salvageable.
2. Before installing Medallion we recommend that the location pocket is clean and free from debris for best adhesion. Blowing with compressed air or using a brush to clean out any debris works best. **(Figure 2.)**
3. Use the provided alcohol wipe to remove any oils or lubricants that would interfere with adhesion of new medallion and allow to dry completely. **(Figure 3.)**



Figure 1.



Figure 2.



Figure 3.

4. If you are installing a Finned design and concerned about a level appearance use a small level and make two marks on the outer edge with a pencil to use as an alignment guide. (Figure 4.)
5. Carefully remove the plastic backing on the preinstalled adhesive. (Figure 5.) **WARNING** Once the adhesive comes into contact with a surface it will be a permanent bond.
6. Align the Medallion as desired and place in the pocket. Press firmly for several seconds to set the adhesive. (Figure 6 & 7.)

Once the Medallion is installed it will be permanent. The adhesive we use is 3M VHB 4905 and is made for use on vehicle applications.



Figure 4.



Figure 5.



Figure 6.



Figure 7.